

### MINIATURE THERMAL OVERLOAD RELAYS

CODE.	CURRENT RANGE AMPS	RATING @ 415V
NR2-11.5 0.4A	0.25 - 0.4 A	0.09 kW
NR2-11.5 0.6A	0.40 - 0.63 A	0.20 kW
NR2-11.5 1.0A	0.63 - 1.0 A	0.37 kW
NR2-11.5 1.6A	1.0 - 1.6 A	0.55 kW
NR2-11.5 2.0A	1.5 - 2.0 A	0.57 kW
NR2-11.5 2.5A	1.6 - 2.5 A	0.75 kW
NR2-11.5 4.0A	2.5 - 4.0 A	1.5 kW
NR2-11.5 6.0A	4.0 - 6.0 A	2.2 kW
NR2-11.5 8.0A	5.5 - 8.0 A	3kW
NR2-11.5 10A	7 - 10 A	4kW



### MANUAL MOTOR STARTERS

CODE.	CURRENT RANGE	RATING @ 415V	AUXILIARY
NS2-25 0.16A	0.1 - 0.16 A	0.08 kW	TOP & SIDE MOUNT
NS2-25 0.25A	0.16 - 0.25 A	0.13 kW	TOP & SIDE MOUNT
NS2-25 0.4A	0.25 - 0.4 A	0.18 kW	TOP & SIDE MOUNT
NS2-25 0.63A	0.4 - 0.63 A	0.20 kW	TOP & SIDE MOUNT
NS2-25 1A	0.63 - 1 A	0.30 kW	TOP & SIDE MOUNT
NS2-25 1.6A	1 - 1.6 A	0.55 kW	TOP & SIDE MOUNT
NS2-25 2.5A	1.6 - 2.5 A	0.75 kW	TOP & SIDE MOUNT
NS2-25 4A	2.5 - 4 A	1.5 kW	TOP & SIDE MOUNT
NS2-25 6.3A	4 - 6.3 A	2.2 kW	TOP & SIDE MOUNT
NS2-25 10A	6 - 10 A	4.0 kW	TOP & SIDE MOUNT
NS2-25 14A	9 - 14 A	5.5 kW	TOP & SIDE MOUNT
NS2-25 18A	13 - 18 A	7.5 kW	TOP & SIDE MOUNT
NS2-25 23A	17 - 23 A	10 kW	TOP & SIDE MOUNT
NS2-25 25A	20 - 25 A	11 kW	TOP & SIDE MOUNT
*NS2-80B 25A	20 - 25 A	11 kW	SIDE MOUNT
*NS2-80B 40A	25 - 40 A	28 kW	SIDE MOUNT
*NS2-80B 63A	40 - 63 A	30 kW	SIDE MOUNT

\*NS2-80B AUXILIARY SOLD SEPARATELY

### NR2 THERMAL OVERLOAD RELAY

CODE.	CURRENT RANGE AMPS	RATING @ 415V
NR2-25G 0.16A	0.1 - 0.16 A	0.05 kW
NR2-25G 0.25A	0.16 - 0.25 A	0.05 kW
NR2-25G 0.4A	0.25 - 0.4 A	0.09 kW
NR2-25G 0.6A	0.40 - 0.63 A	0.20 kW
NR2-25G 1.0A	0.63 - 1.0 A	0.37 kW
NR2-25G 1.6A	1.0 - 1.6 A	0.55 kW
NR2-25G 2.0A	1.5 - 2.0 A	0.57 kW
NR2-25G 2.5A	1.6 - 2.5 A	0.75 kW
NR2-25G 4.0A	2.5 - 4.0 A	1.5 kW
NR2-25G 6.0A	4.0 - 6.0 A	2.2 kW
NR2-25G 8.0A	5.5 - 8.0 A	3 kW
NR2-25G 10A	7 - 10 A	4 kW
NR2-25G 13A	9 - 13 A	5.5 kW
NR2-25G 18A	12 - 18 A	7.5 kW
NR2-25G 25A	17 - 25 A	11 kW
NR2-36G 32A	23 - 32 A	15 kW
NR2-36G 36A	28 - 36 A	18.5 kW
NR2-93G 32A	23 - 32 A	15 kW
NR2-93G 40A	30 - 40 A	18.5 kW
NR2-93G 50A	37 - 50 A	22 kW
NR2-93G 65A	48 - 65 A	30 kW
NR2-93G 70A	55 - 70 A	32 kW
NR2-93G 80A	63 - 80 A	37 kW
NR2-93G 93A	80 - 93 A	45 kW
NR2-150G 104A	80 - 104 A	45 kW
NR2-150G 120A	95 - 120 A	45 kW
NR2-150G 125A	80 - 125 A	55 kW
NR2-150G 150A	110 - 150 A	75 kW
NR2-200G-160A	100 - 160 A	75 kW
NR2-200G-200A	125 - 200 A	95 kW
NR2-630G 250A	160 - 250 A	160 kW
NR2-630G 315A	250 - 315 A	160 kW
NR2-630G 400A	315 - 400 A	200 kW
NR2-630G 500A	400 - 500 A	250 kW
NR2-630G 630A	500 - 630 A	375 kW



### MANUAL MOTOR STARTER ACCESSORIES

CODE.	DESCRIPTION	AUX. CONTACT
NS2-AU11	SIDE MOUNT AUXILIARY	1NO + 1NC
NS2-AE11	TOP MOUNT AUXILIARY	1NO + 1NC
NS2-AU11/80	SIDE MOUNT AUXILIARY (FOR NS2-80B)	1NO + 1NC
NS2-MC	IP65 EMPTY ENCLOSURE (MMS)	N/A
NS2-UV	UNDERVOLTAGE TRIP	N/A

### TIME DELAY RELAY & BLOCK

CODE.	DESCRIPTION	CURRENT	AUX. CONTACTS
F5-T2/3	PNEUMATIC TIMER	0.1~3 SEC DELAY ON	1NO + 1NC
F5-T2/30	PNEUMATIC TIMER	0.1~30 SEC DELAY ON	1NO + 1NC

### CONTACTOR AUXILIARY

CODE.	DESCRIPTION	CURRENT	AUX. CONTACTS
F4-20	TOP MOUNT AUXILIARY	10A	2NO
F4-11	TOP MOUNT AUXILIARY	10A	1NO + 1NC
F4-02	TOP MOUNT AUXILIARY	10A	2NC
F4-40	TOP MOUNT AUXILIARY	10A	4NO
F4-31	TOP MOUNT AUXILIARY	10A	3NO + 1NC
F4-22	TOP MOUNT AUXILIARY	10A	2NO + 2NC
F4-13	TOP MOUNT AUXILIARY	10A	2NO + 1NC
F4-04	TOP MOUNT AUXILIARY	10A	4NC
NCF1-11C	SIDE MOUNT AUXILIARY	10A	1NO + 1NC

### REMOTE MOUNTING BLOCK

CODE.	OVERLOAD RANGE
NR2-11.5	For NR2-11.5 Range
NR2-25	For NR2-25 Range
NR2-36	For NR2-36 Range
NR2-93	For NR2-93 Range